


# USER MANUAL

ORIGINAL USER MANUAL.

0458-395-5411

REV: 6



## LOGOSOL B751 PRO

### BAND SAWMILL



Read through the user manual carefully and make sure you understand its contents before using the saw.



This user manual contains important safety instructions.



**WARNING!** Incorrect use can result in serious or fatal injuries to the operator or others.



This product consists of several accessories, each with its own manual. Read these manuals before starting assembly to understand the contents, functions, and settings.

EN

## THANK YOU FOR CHOOSING A LOGOSOL MACHINE!

**W**e are very pleased that you have demonstrated your confidence in us by purchasing this sawmill, and we will do our utmost to meet your expectations.

LOGOSOL has been manufacturing sawmills since 1989, and in that time we have supplied approximately 50,000 machines to satisfied customers the world over.

We are concerned with your safety and ensuring that you achieve the best possible results with your sawmill. We therefore recommend that you take the time to read this user manual carefully before starting your sawing. Remember that the machine itself is only a part of the value of the product. Much of the value is also to be found in the expertise we pass on to you in the user manual. It would be a pity if that was not utilised.

We hope you will be thoroughly satisfied with your new machine.

A handwritten signature in black ink, reading 'Bengt-Olov Byström'.

**Bengt-Olov Byström**  
Founder,  
Logosol in Härnösand



LOGOSOL continuously develops its products.  
For this reason, we must reserve the right to modify  
the configuration and design of our products.  
Document: LOGOSOL B751 Pro User Manual  
Manual, SKU: 0458-395-5410  
Text: Mattias Byström, Robert Berglund, Martin Söderberg, Jonas Höglund  
Illustrations: Mattias Byström, Martin Söderberg, Robert Berglund, Anna Fossane  
Last revised: January 2026  
© 2026 LOGOSOL, Härnösand, Sweden

## TABLE OF CONTENTS

|                                                      |    |
|------------------------------------------------------|----|
| General information                                  | 4  |
| Description of the band sawmill                      | 5  |
| Safety instructions                                  | 6  |
| Technical data                                       | 8  |
| Component parts                                      | 10 |
| Mounting the rail                                    | 12 |
| Adjusting the rail                                   | 18 |
| Fitting the saw head to the rail                     | 19 |
| Installing the handle: see the separate user manual  | 21 |
| Installation of the motor: see separate instructions | 22 |
| Adjustment sequence                                  | 23 |
| Other settings                                       | 29 |
| Sawmill features                                     | 32 |
| Wiring diagram                                       | 33 |
| Usage                                                | 34 |
| Chip collection                                      | 36 |
| Start / stop                                         | 37 |
| Operating instructions                               | 38 |
| Maintenance                                          | 43 |
| Troubleshooting                                      | 46 |
| Machine declaration                                  | 48 |

## GENERAL INFORMATION

This user manual, the instruction manual for the motor, the band sawmill's assembly instructions, and the instructions for accessories, are to be regarded as constituent parts of the band sawmill. They must also remain with the band sawmill if it is sold on.

Responsibility for correct assembly, commissioning and use of the band sawmill rests with whoever has assembled it and the people who use it.


## DESCRIPTION OF THE BAND SAWMILL

### B751 PRO

Forwards


Back

Page



# DESCRIPTION OF THE BAND SAWMILL

## LOGOSOL B751 PRO



## SAFETY INSTRUCTIONS

### KEY TO SYMBOLS



**WARNING!** This symbol means that you have to take particular care. It is always accompanied by information on the specific risk.



**ATTENTION.** A warning comes after this symbol. Pay particular attention where this symbol appears in the manual text.



For your own safety and that of others, do not use the bandsaw mill or handle bandsaw blades without first reading through and understanding the contents of this user manual in its entirety.



**WARNING!** Cutting tools: Incorrect use of the machine can lead to life-threatening injuries. Bandsaw blades are extremely sharp and dangerous.



Always wear protective gloves (class 1) when fitting and working with the band sawmill or handling bandsaw blades. Risk of lacerations when handling bandsaw blades and some sheet metal. Bandsaw blades and motor parts can be hot after sawing.



Always use approved hearing protection when working with the machine. Even brief exposure to high frequency noise can damage your hearing. Always use close-fitting safety goggles when working with the machine or handling bandsaw blades. Under certain circumstances the use of a protective mask may also be advisable. This would primarily apply if you are sawing dry wood or sawing indoors.



Always wear approved protective footwear with saw protection, steel toe-caps and non-slip soles when working with the machine or handling bandsaw blades.



Always wear full-length protective trousers when working with the machine or handling band blades. Never wear loose-fitting clothing, scarves, neck chains, etc. that can get caught in the machine when working. Secure loose hair before working with the Band sawmill.

# SAFETY INSTRUCTIONS

## THE BAND SAWMILL'S SAFETY EQUIPMENT

 **WARNING!** Never use the machine if the safety equipment is defective..

 Safety equipment must be checked and maintained.

Here is a description of the items of safety equipment on the band sawmill, together with their features.

### Interlocking the band wheel guards

One of the hinges on the band wheel guards is fitted with safety switches. The hatches must be closed before using the machine.

### Rail end stops

These mechanical stops prevent the saw carriage rolling off the end of the rail.

## OPERATOR

 **WARNING!** Whenever the machine is used, approved personal protective equipment must always be used.

 Persons under the age of 18 may not use the band sawmill or handle bandsaw blades.

 Never use the machine or handle bandsaw blades if you are tired, if you have consumed alcohol or are taking medicine that can impair your sight, judgment or control over your body.

## WORK SITE

 **WARNING!** Never operate a band sawmill with a combustion engine in an enclosed or poorly ventilated area. Doing so can cause death by asphyxiation or carbon monoxide poisoning.

 The use of the band sawmill and the handling of saw blades must be carried out in broad daylight or in adequate work lighting.

 Keep the workplace free of debris, pets, children, obstacles and anything else that may distract the operator.

 Choose an work site where the supporting ground is tightly compacted and level, with generous space for the band sawmill, log piles and sawn wood. If possible, position the band sawmill so that the sawdust is blown away from the operator station. Set up the band sawmill on a level surface, with at least 5 m of clear, obstacle-free space all around the machine. If the band sawmill is to be set up permanently, we recommend supporting the bandsaw rail on cement slabs or wooden blocks (15 cm x 15 cm) placed under each crossbar.

 Always have an ABC type handheld fire extinguisher (min. 6 kg) readily available at the work site.

 Always have a complete first aid kit to hand at the work site.

## TECHNICAL DATA

| LOGOSOL B751 PRO                                      |                                         |
|-------------------------------------------------------|-----------------------------------------|
| RAIL COMPONENT                                        |                                         |
| Rail length, standard                                 | 5.85m                                   |
| Rail length, extension                                | 1156 mm                                 |
| Track width                                           | 800 mm                                  |
| Overall width                                         | 850 mm                                  |
| Height                                                | 240 mm                                  |
| Weight (5.85 m rail)                                  | 240 kg                                  |
| SAW CARRIAGE                                          |                                         |
| Length                                                | 900 mm                                  |
| Width                                                 | 1975 mm                                 |
| Height                                                | 1700 mm                                 |
| Weight                                                | 178 kg                                  |
| Volume, water reservoir                               | 7.5 litres                              |
| Feed rate                                             | Manual                                  |
| CAPACITY                                              |                                         |
| Max. log diameter                                     | 751 mm                                  |
| Max. sawing width                                     | 600 mm                                  |
| Effective saw length (standard)                       | 4.85 m                                  |
| BANDSAW BLADE                                         |                                         |
| Type and size                                         | 3843x33 pitch 22 mm                     |
| Band wheel diameter                                   | 500 mm                                  |
| Band wheel, rotational speed                          | 1000 v/min                              |
| Saw blade, speed                                      | 30 m/s                                  |
| SAW MOTOR(S)/ENGINE                                   |                                         |
| Electric motor drive                                  | 8 kW, 400 V (weight: 40 kg)             |
| Petrol engine                                         | Briggs & Stratton 18 hp (weight: 34 kg) |
| Volume, fuel tank                                     | 5 litres                                |
| NOISE LEVEL/VIBRATIONS                                |                                         |
| Equivalent sound pressure level at ear of operator 1) | 88.4 dB(A)                              |
| Sound power level (estimated) 2)                      | 109.4 dB(A)                             |
| Vibration level in handle 3)                          | <2.5 m/s <sup>2</sup>                   |

1) The typical distribution measurement for equivalent sound pressure level is a standard deviation of 2 dB(A)



2) The typical distribution measurement for sound power level is a standard deviation of 3 dB(A)

3) The typical distribution measurement for vibration level in the handles is 1 m/s<sup>2</sup>



## BOLTS/NUTS

Definition of the fasteners on following pages.



## ADDITIONAL SYMBOLS

The following symbols are used in addition to those shown above to describe part design.



When this symbol appears during assembly, parts must be lubricated before installation. Lubricate affected parts with universal grease.



This symbol describes the recommended lifting point for heavy lifts.



This symbol describes the sawing direction and reappears during assembly.



Make the joint finger-tight.


## DIMENSIONS/LENGTH

The dimensions of the fasteners are printed as a diameter dimension (M) ISO 68-1. This is followed by a length dimensions for bolts/screws; the dimension of a bolt/screw is the part of the bolt/screw that disappears into the material in which it is mounted.


**(Diameter)**      **(Length)**

M8      x      20

## COMPONENT PARTS
















1st — 8450-000-000



|  |          |               |
|--|----------|---------------|
|  | — 10 x — | 03-01971      |
|  | — 14 x — | 03-01973      |
|  | — 4 x —  | 03-01972      |
|  | — 2 x —  | 03-02514      |
|  | — 2 x —  | 03-02517      |
|  | — 2 x —  | 03-01985      |
|  | — 2 x —  | 03-01983      |
|  | — 2 x —  | 03-01448      |
|  | — 4 x —  | 03-02180      |
|  | — 4 x —  | 03-02516      |
|  | — 2 x —  | 03-01977      |
|  | — 2 x —  | 8210-001-0020 |
|  | — 1 x —  | 02-00247      |
|  | — 1 x —  | 8300-005-0150 |
|  | — 1 x —  | 03-03054      |
|  | — 1 x —  | 8300-005-0100 |
|  | — 1 x —  | 01-00655      |
|  | — 2 x —  | 03-01880      |
|  | — 1 x —  | 8300-005-0005 |
|  | — 1 x —  | 8200-005-0200 |
|  | — 1 x —  | 8300-005-0300 |

# COMPONENT PARTS

|                                                                                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>8300-005-0010   |  — 58 x – M8x16<br> — 58 x – M8                                                                                                                                                                                                                                                                                                                                                                                                |  — 1x 8300-005-0005                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <br>8300-005-0020   |  — 4 x – M8x25<br> — 4 x – M8x12<br> — 10 x – M8x20<br> — 8 x – M8<br> — 2 x – M8                                                                                          | <br>8200-005-0200  — 6x 9291-020-0005<br> — 2 x 03-01464<br> — 4 x 9026-015-0002<br> — 2 x 03-01465<br> — 4 x 9029-011-0001<br> — 4 x 03-01982<br> — 1 x 03-01772<br> — 1 x 03-01773 |
| <br>8300-005-0030  |  — 20 x – M16                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <br>8300-005-0040 |  — 16 x – M12x90<br> — 16 x – M12<br> — 16 x – M12                                                                                                                                                                                                                                                                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <br>8300-005-0050 |  — 32 x – M12x140<br>  — 32 x – M12                                                                                                                                                                                                                                                                                                     | <br>8300-005-0300  — 4 x 03-02181<br> — 10 x 03-02007<br> — 4 x 03-01905<br> — 10 x 9034-011-0002                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <br>8300-005-0060 |  — 4 x – M6x65<br> — 4 x – M6<br> — 4 x – M6<br> — 6 x – M8x95<br>  — 6 x – M8 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |



## RAIL ASSEMBLY

Start assembling the sawmill by mounting the rail. The rail sections are placed under the saw head in the pallet. Assembly work involves heavy lifting, and two people are required to help with assembly.



**WARNING!** Heavy lifting! Risk of injury.



**WARNING!** Risk of entrapment.



Two people are always required to help with heavy lifting.



Wear protective gloves and handle the engine whenever and wherever it is placed on the motor shelf.

### **ADDITIONAL EQUIPMENT:**


There are accessories for this machine that may affect the sequence of assembly in this manual. Read through the assembly instructions in the various manuals before starting work for an overview of the various procedures.



Now it is time to assemble the rail.  
Follow the assembly steps carefully, and adopt an ergonomically correct posture when working. Work on a surface that is as flat as possible, as this will make it easier to set the rail.




Read through all the assembly instructions before starting assembly, then follow the instructions step by step as you work.



**1**



Skip step 1 when installing trailer kits and accessories that require fixed support legs (see the manual for the product in question).



8300-005-0100



10 x



8300-005-0030



8300-005-0300



10 x




20 x – M16




20 x

**2**



8300-005-0150




4 x

**3**





8300-005-0050



4 x – M12x140




4 x – M12





4


5



12 x



8300-005-0050



12 x – M12x140



12 x – M12

Now repeat steps 2 to 5 for the second rail.


6



These two racks should not be fitted at this stage if the machine is to be fitted with hydraulics.



8300-005-0040




16 x – M12x90








16 x – M12



16 x – M12



78,5mm





**7**




8300-005-0010



4 x – M8x16



4 x – M8



8-10mm

**8**




8300-005-0010



4 x – M8x16



4 x – M8



**9**





8300-005-0010




38 x – M8x16



38 x – M8




8-10mm






**10**

Install the first rail bars in the rail pipes. Please note that the short pieces must be used at the ends of the rail. The first short piece will be the one on the sides, while the first longer piece will be fitted on top of the first one. The small wedge must be placed at the end. The rail pieces must overlap one another. Tighten the rail bar screw joints finger-tight during assembly before finally adjusting the rail.








Repeat this process on each corner.



**11**

The rail plates must overlap one another. These are then secured with the screw joint in the cut-out pockets in each mount as illustrated. Then repeat this assembly step for the second rail pipe.







12



8300-005-0020

8200-005-0200



4 x – M8x12



4 x



13



8300-005-0010



12 x – M8x16



12 x – M8



14



8300-005-0020



6 x – M8x20



6 x – M8



15



8300-005-0020

8200-005-0200



4 x – M8x25



4 x – M8x20



2 x – M8



2 x – BRB M8



2 x




2 x

6 x



2 x





2 x



2 x



2 x



## ADJUSTING THE RAIL

Now aim and measure along the string to check that the distance between the string and the rail is consistent along its entire length. To adjust the straightness, move the rail pieces up or down where the straightness deviates.

**Tip:** Place shims under the rail components so that you can control the height while tightening.




### Important!

This step is critical to sawmill precision. Be meticulous and spend some extra time on this step.

Once the rail has been straightened, check that all rail joints are even and that the outer rail bars are at the same height as the ones on the inside. The aim is to ensure that all joints are as even as possible. Adjust and tighten the screw joints as you work. Tighten the aligned half of the screw joints for the rail when the rail is aligned over its entire length and the joints are even. Then repeat this procedure on the other side of the rail to complete the adjustment.



### Support legs

If the machine is equipped with support legs, they must be fitted before starting the next step.




## MOUNTING THE SAW HEAD ON THE RAIL

Lift the sawhead into place on the rail. The total weight of the sawhead is 178 kg. Use an approved lifting sling attached to the sawhead's lifting points, as shown in illustration A or B. Perform the lift with lifting equipment suitable for the situation.



### Important!

Take care to ensure that the saw carriage surrounds the rail.




**Danger, overturning hazard!**  
**Critical assembly**



The anti-tip wheels must be mounted on the underside of the saw carriage when the saw head is mounted on the rail.



Start by removing the flange nuts on the outside of the bogie tube. They will be needed in step 3. Leave the screw where it is. This will be needed later on during assembly. Install the rail scraper.





**2**




8300-005-0300

8300-005-0060



2 x



2 x – M6x65



2 x – M6




2 x – M6



2 x

**3**



3 x – M8x95



3 x – M8

Use existing nuts from step 1.



2 x – M10

**4**

0



Repeat steps 1 to 4  
for the other side.

**5**



2st — 03-01880

**6**




## INSTALLING THE HANDLE: SEE THE SEPARATE USER MANUAL



Now it is time to install the handle.




The instructions for installing the handle are provided in a separate attachment; please refer to the instructions for your specific handle. Once installation is complete, proceed to the next step in these instructions.



— 1x ——— 01-00655

Options 1 and 2.


Use the chain extender if you go for option 2.



## INSTALLATION OF THE MOTOR: SEE THE SEPARATE USER MANUAL



It is now time to fit the engine. The instructions for fitting the engine are supplied in a separate attachment: see the instructions for the engine you will be working with. When assembly is complete, carry on with the section entitled Adjustment sequence on the next page of this user manual to complete the adjustment sequence before starting the machine.



## ADJUSTMENT SEQUENCE



Read through all the set-up instructions before starting to set up, then follow the instructions step by step as you work.



### **IMPORTANT!!**

It is important to adjust the saw head before starting to ensure satisfactory sawing and the correct functioning of the sawmill. Follow the adjustment sequence meticulously. Certain adjustments affect other machine settings. That is why it is important to follow the sequence below.


- 1 Adjust the rail horizontally
- 2 Adjust the wheels
- 3 Longitudinal blade position / Adjust the longitudinal blade position
- 4 Adjust the saw blade so that it is parallel to the log beds
- 5 Adjust the adjustable blade guide horizontally
- 6 Adjust the blade so that it is parallel to the rail
- 7 Tensioning of the throttle cable

## ADJUSTMENT SEQUENCE

1


### ADJUST THE RAIL HORIZONTALLY

It is important that the rail is completely level so as to ensure that it functions well. We have previously set the straightness of the rail in longitudinal direction. Now the rail has to be adjusted horizontally along the short side. Place a spirit level on a log bed, then adjust the rail using the feet until the rail is horizontal. Then repeat this procedure for all log beds until the whole rail is horizontal.



### ADJUSTMENT OF THE FEET

The feet can be adjusted from above using an Allen key. Once adjustment is complete, the position is fixed with the check nut on the inside of the tube.





2

### ADJUST THE WHEELS

The angle of the wheels must be adjusted so that they are perpendicular to the log beds. With the saw head set to the bottom position, check the perpendicularity between the wheels and the log beds. It is useful to place the angle iron on a straightedge extending between two log beds. Adjust by loosening the lock nut first, then tightening the adjusting screws on the wheel axle until perpendicularity is achieved. Tighten the lock nuts and adjusting screws.

Place the set square on a straightedge






## ADJUSTMENT SEQUENCE

### 3

#### LONGITUDINAL BLADE POSITION

The longitudinal blade position over the wheels is adjusted using the horizontal adjusting screws, i.e. the screws on the outside of the axle mountings. The lock nut must be opened first when adjusting the blade position. The adjusting screw must be turned clockwise to compensate if the saw blade wanders forward on the wheels. Turn the screw anticlockwise if the blade wanders backwards. Adjust in small increments. Tighten all lock nuts and adjusting screws when adjustment is complete.

**TIP:** You may need to loosen the upper adjusting screw slightly before adjusting the blade.




#### LONGITUDINAL BLADE POSITION

The position of the saw blade in the longitudinal direction is important for the sawing result. Positioning the blade with the blade body centred over the drive belt located in the recess in the wheel is recommended for best results.

Start by fitting the blade so that the protrusion on both sides of the drive belt to the sides of the blade body are of the same size. Then tension the blade. Spin the wheels manually and check that the longitudinal blade position on the wheels remains unchanged. Spin the wheels through at least three revolutions. Perform adjustment as instructed in the next paragraph if the blade wanders forward or back on the wheels. If the blade runs straight on both wheels, check that the blade runs in a straight line between the wheels. This is checked by looking along the trailing edge of the blade on the top of the wheels.

When the blade is running in a straight line. Close the covers and start the sawmill. Open the throttle so that the wheels start to turn, then release the throttle. Open the covers and check that the longitudinal position of the blade is unchanged. If so, the setting is correct.



If the blade curves in the sawing direction, the blade is too far forward on the wheels. If it curves in the other direction, it is too far back.

## ADJUSTMENT SEQUENCE



4

### ADJUST THE SAW BLADE PARALLEL TO THE LOG BEDS

It is important for the saw blade to be parallel to the log beds to ensure the proper functioning of the sawmill. Measure the distance vertically down from the blade to the log bed, then note down the values.

It is important for the blade guide rollers to be removed for this setting operation.


Adjust the measurement difference between the measurement points. Tighten the saw head adjusting screws until the measurements match at both measurement points.



5

### ADJUST THE ADJUSTABLE BLADE GUIDE HORIZONTALLY

The adjustable blade guide and guard needs to be adjusted so as to achieve straight kerfs in all positions. Install the blade guide rollers. Then move the blade guide and guard to its innermost position. Place a spirit level on top of the blade guide, then adjust until the blade guide and guard is horizontal. When this has been done, shim the fixed blade guide roller until the same dimension is achieved between the blade tension rollers and the log bed.




# ADJUSTMENT SEQUENCE

## TENSION THE BLADE GUARD ARM


It is important for the blade guard arm to move smoothly in the attachment plate to ensure proper functioning of the sawmill. Release the Allen head bolt on the blade guard plate, then push the wheel downwards using a screwdriver as illustrated.

Take care to ensure the blade guard arm is straight between the wheels and runs smoothly.



## ADJUST THE BLADE GUARD ARM PARALLEL TO THE BLADE

To adjust the parallelism of the blade guard arm with the saw blade, loosen the three fastening screws on the outside of the attachment, then adjust the parallelism using the adjusting screw that attaches to the back cover.



## ADJUSTMENT SEQUENCE

6

### ADJUST THE BLADE SO THAT IT IS PARALLEL TO THE RAIL



It is important for the saw blade to be parallel to the rail to ensure proper operation of the sawmill. Place the Blade Align on the saw blade, as close to one of the blade guide rollers as possible. Place the Blade Align over a tooth with no set. Now measure from the leading edge of the Blade Align (measurement point 1) vertically down to the log bed. Note down the value from measurement point 1. Move the saw head, then repeat the measurement from the trailing edge of the Blade Align (measurement point 2). Compare the values. The values at measurement point 1 and measurement point 2 must be the same.

If the values are not the same, tighten the adjusting screws for the blade guide roller until the measurements match at both measurement points. One way of facilitating adjustment is to work on the basis of the value from measurement point 1, compare it with the value from measurement point 2, and then adjust measurement point 2 up or down by half the difference. When you have achieved parallelism, repeat the adjustment procedure at the second blade guide roller.


7

### THROTTLE CABLE TENSION


The throttle cable tension can be adjusted by tightening the adjusting screw holding the cable housing. Undo the adjusting screw until depressing the throttle fully results in full throttle at the engine. Then lock the adjustment using the check nut.



Adjust half the difference at measurement point 2



Check nut



## OTHER SETTINGS




Read through all the set-up instructions before starting to set up, then follow the instructions step by step as you work.



The following settings are important for satisfactory operation of the sawmill, but they do not affect one another and so there is no need to implement them in any particular order.


### RAIL SCRAPERS

The saw carriage has rail scrapers at the ends. It is important to perform regular checks to ensure that these run against the rail.




### BLADE TENSION

Tension the saw blade by turning the T-handle to the right. Read off the blade tension on the gauge that can be seen inside the band wheel guards. The blade is tightened until the red line is centred on the arrow in the opening for the blade tension spring.




### CHAIN LINKAGE

The handle's chain linkage must be extended to ensure that the lifting mechanism works properly. Start by loosening the tensioner's fastening screw, then move the tensioner towards the chain until the chain is tensioned slightly. Then tighten the screw joint.



### SET THE GAUGE


It is necessary to adjust the gauge so that it shows a correct value between the log bed and the blade. Proceed as follows: Measure the distance vertically down between the saw head and a log bed. Note down the distance. Now fit the magnetic gauge on the gauge plate so that its value at the top of the pointer matches with the value noted.



## OTHER SETTINGS


### LOG SUPPORT

It is important for the relationship between the log bed and the log support to be perpendicular to ensure the proper functioning of the sawmill. This is adjusted by turning the adjustment handle in the lower part of the log support. Check the perpendicularity using a set square.




### DRIVE BELT TENSION

The drive belt must be tensioned correctly to prevent it wearing on the pulley. The tensioning wheel can rotate around its lower attachment. Tension the belt until the value stated below is reached at the checkpoint.



### WATER RESERVOIR

The sawmill water reservoir needs to be filled before use. This is done in the tank opening on the back of the saw carriage. The tank volume is 7.5 litres.




# OTHER SETTINGS

## ENGINE INSPECTION BEFORE STARTING

The engine must be filled with oil and refuelled before starting the sawmill for the first time. Place the saw head in the bottom position to make this job easier. Detailed information about the engine can be found in the engine's user manual, which is supplied.


### Tip:

Work with the saw head in the bottom position to facilitate access to the engine.




## BLADE GUIDES


The blade guides clamp the blade down by 3 mm compared to the wheels.



The guides can adjust the blade angle in the sawing direction by adjusting the upper and lower adjusting screws. The guides must be adjusted so that they are parallel to the trailing edge of the blade. This is done by adjusting the outer and inner adjusting screws. It is important for the blade guide roller to run parallel to the blade. Be thorough when setting this feature.



The guides can be adjusted in and out by pulling the shaft after releasing the adjusting screws. The trailing edge of the blade should be about 3 to 5 mm from the flange of the blade guide roller.




## SAWMILL FEATURES

### GAUGE FEATURE

The sawmill has two gauges: a millimetre gauge showing the distance between the log bed and the saw blade, and a blade-compensated gauge showing a range of different board thicknesses in inches. The blade-compensated inch gauge can be adjusted using a knob which is located at the bottom of the gauge. One additional feature is the Last Cut indicator, which is used as an instrument to help the user to remember the saw head position at the last kerf.


### LAST CUT INDICATOR

To use the Last Cut feature, push the knob down against the pointer before you start sawing. When the saw head is then raised in order to retract the machine prior to the next kerf, the knob "remembers" where the saw head was at the last kerf. When the saw head is then lowered for the next kerf, the Last Cut knob can be used as a reference for the last cut surface.



### PARKING LOCK

The sawmill comes equipped with two hasps that lock the saw head in position when it is moved towards the end stop at either of the rail ends. To release the lock, lift the hasp with your foot before moving the saw head. On the rail end, the lock can be lifted so that it does not lock automatically by removing the screw that restricts the movement of the lock.



### LOG CLAMP

The sawmill comes with two log clamps so that the log can be secured when sawing. The log clamp feature is eccentric.


Start by adjusting the eccentric plate so that it rests against the log that is to be clamped. This is done by rotating the plate clockwise. Continue tensioning by turning the handle clockwise as shown. The actions are performed in reverse order in order to release the tension. The plate and handle are then turned anticlockwise.



## SAWMILL FEATURES


### WATER COOLING

Water cooling is controlled by means of a lever in the side panel in front of the operator. The lever is perpendicular to the panel in its initial position. The lever is pulled backwards to turn on the water flow. The water cooling flow is adjusted by clamping the cooling hose in the elongated groove in the motor shelf.





## WIRING DIAGRAM

### SAFETY SWITCH WIRING DIAGRAM



Elesa CFSQ,  
60-SH-6-FAS-2

Safety switch



## USAGE

### USAGE



**WARNING!** Cutting tools: Always stand behind the saw carriage and keep both hands on the handles when operating the machine. Never stand in front of the saw carriage or bandsaw blade. Never pull the saw carriage through a kerf.



**WARNING!** Risk of entrapment and rotating parts: Even slight pressure on the saw head release mechanism can cause the saw head to drop in an uncontrolled manner and the crank to start rotating at speed, which may result in injury.



**WARNING!** Never modify this machine so that it no longer conforms to the original configuration. Do not use the machine if it has been modified. Never use any accessories apart from those that are recommended in this user manual.



**WARNING!** A broken bandsaw blade can eject bandsaw blade fragments at high speed via the chip ejector.



Make sure there is no one on the chip ejection side of the band sawmill while it is working. The risk of bandsaw blade breakage increases if it has not been properly fitted or maintained.



The bandsaw blades and plastic sawmill parts are resistant to temperatures down to -25 °C. Do not use the band sawmill in temperatures below -25 °C.



Make sure that the machine has been properly assembled and maintained in line with the enclosed assembly instructions as well as these instructions.



Never work alone. Always make sure there is another adult within earshot in case you need to call for help.



**WARNING!** Risk of fragments flying off dirty logs.



Always inspect the logs so that there are no objects wedged in the bark before sawing.



Do not stand between the log pile and the band sawmill. Always stand to the side of the log pile when handling the logs. Never stand in any location where a log may fall on you.

#### Hazard area:



The minimum safe distances around the band sawmill are shown in Figure 1. Please note that the safe distance on the left side of the band sawmill is 15 m, as there is a risk of saw blade parts being ejected through the chip ejector if the saw blade breaks. The extent of the hazard area on the other sides is 5 m. [Figure 1]



**WARNING!** Keep hands, arms, legs and other body parts well away from the bandsaw blade, cables and other moving parts.



**WARNING!** Risk of collision with the saw carriage.



Always use the parking lock when working with the saw carriage.



**WARNING!** Risk of tripping on rail and crossbars.



Never take a short cut over the rail. Suspend electrical cables so that they are not damaged and do not present a trip hazard.



**WARNING!** Never run the combustion engine in enclosed spaces. Ensure good ventilation. The exhaust gases contain harmful substances that are potentially fatal.



**WARNING!** Risk of entrapment between the sawmill and the log during loading.



The log pile must always be secured by placing a reliable retaining strap around the logs, for example (see Operating instructions).



Never climb onto the rail or the log bed crossbars.

## USAGE

Hard knots may cause deviations in the outcome of the sawing.

### BEFORE EACH USE:

Check that

- the operator is wearing the prescribed personal protective equipment
- the maintenance prescribed has been carried out
- the bandsaw blade is stationary while the engine is idling
- the machine has been erected so that it is stable and the rail is supported along its entire length
- the anti-tip wheels and rail end stops on the saw carriage are in place
- all components on the band sawmill are secure and serviceable
- all the safety equipment on the machine is in place and in proper working order
- the bandsaw blade is properly installed and runs freely in the right direction.

### Before each kerf:

Check that

- there are no other persons or pets within the danger zone of the machine
- there are no obstacles at the work site that could cause a trip hazard or be a nuisance
- the bandsaw blade runs clear of the log supports and log clamp
- the rail is clear of debris, dirt, etc.

- the workpiece is secured in place
- the adjustable saw blade guard is set correctly to accommodate the maximum width of the workpiece.

### When in use:



**WARNING!** Risk of burn injuries. The engine and its silencer become very hot during operation, and remain hot for a while after the engine has been shut down. This also applies when the engine is idling.




**WARNING!** Fire hazard. Petrol and petrol vapours are highly flammable. Bear in mind the fire, explosion and inhalation hazards involved.



The engine must have been shut down and allowed to cool for 10 min before fuel is added.

Always shut down the combustion engine when leaving the operator station, even you are only away for a few moments to deal with sawn timber or carry out maintenance.



Figur 1.

## USAGE

### STORAGE

The bandsaw blade must be removed from the machine and stored out of reach of children and other persons, even if the machine will not be used for just a short time.

**When stored for longer periods the following applies:**

- empty the fuel tank and coolant reservoir,
- remove the bandsaw blade from the machine,
- close the fuel valve,
- lock the saw carriage in position.

Store the band sawmill in a place that is not accessible to children or other persons, preferably in a locked room.

- ! Blade tension must be released at the end of each completed shift to reduce wear on the bandsaw blades.

### MAINTENANCE

- ! **WARNING!** Risk of serious injury.

- ! Turn the ignition switch to OFF and close the fuel valve before servicing or performing maintenance on the machine.

- ! **WARNING!** Risk of burn injuries. The engine and its silencer become very hot during operation, and remain hot after the engine has been stopped.

- ! Allow the engine and silencer to cool down before servicing or performing maintenance on the machine.

## CHIP COLLECTION

The sawmill can be run without chip extraction if it is used outdoors.

- ! Make sure that the sawdust collecting at the machine is removed at regular intervals using a spade, for example. A capacity of at least 800m<sup>3</sup>/h is required if chip extraction is connected.

### MOVING THE BAND SAWMILL

- ! **WARNING!** Risk of entrapment.

- ! When lifting and moving machine parts, keep persons and animals outside the 5 m danger zone around the machine. Secure the load during transport.

- ! The saw carriage and rail component must not be lifted or transported while assembled, but must be transported separately.

**Lifting the saw carriage:** Remove the anti-tip wheels of the saw carriage, one on either side, and then use safe lifting equipment to lift the saw carriage using the lifting eyes right at the top of it. Weight, see Technical data.

**Lifting of rail component:** Use pallet forks or a fork lift to lift the rail from below. Place a protective layer of wood material on the forks before lifting. Make sure that the rail component is well balanced and secure the load to the pallet fork before transporting it. Weight, see Technical data.

### REFUELLING

- ! **WARNING!** Risk of burn injuries. Petrol is a highly flammable liquid.

- ! Wait until the machine's engine has cooled down before refuelling it. Turn the ignition switch to OFF and close the fuel valve.

Refuelling: refuel the engine with the saw head in its bottom position and the saw carriage in its locked position at either end of the rail. Use a funnel and try your best to avoid spilling fuel.

- ! Extraction hose: Any extraction hose connected to the sawmill must be fitted with a coil that can be earthed.

# STARTING AND STOPPING

## STARTING

1. Open the fuel valve by moving the slide control to the right to the "ON" position.
2. To start a cold engine, set the choke to closed position (lever to the left). To start a warm engine, leave the choke in open position (lever to the right).
3. Set the ignition key to "ON".
4. Gently pull the starter handle until you feel resistance, then pull firmly. Carefully return the starter handle.
5. Open the throttle by squeezing the throttle control all the way to the end position. This will increase the speed of the combustion engine to its operating range, and the bandsaw blade will start.
6. If the choke is in closed position, gradually move the control to open position as the engine warms up.

## STOPPING

The saw blade is stopped by releasing the throttle control on the push handle. The bandsaw blade is then decelerated to a standstill, and the engine drops to idling speed. Then shut down the engine by turning the ignition key to "OFF" and then closing the fuel valve.

## OPERATING INSTRUCTIONS

### LOG PILE

Do not make the log pile more than 1 m high.

Logs that are contaminated with earth, sand or clay significantly reduce the service life of the bandsaw blade and increase the risk of it breaking. Avoid dragging the logs along the ground, and try to keep them as clean as possible

It may also be a good idea to separate out the various types of timber into different log piles.

### LOG TABLE

Logs can be loaded from either side of the band sawmill. The log pile must be secured before each sawing operation if it is on the same side as the operator.

Set the log table to the same height as the crossbars on the bandsaw. The log table should end 10 cm from the band sawmill if it is placed on the left side of the band sawmill. If the log table is placed on the operator's side, it should stop about 1 m from the band sawmill and movable ramp boards should be used between the log table and the sawmill. Make sure the log table has large wedges at its trailing edge so that the logs cannot roll off.

 Make sure that the logs nearest to the band sawmill are secured to prevent them rolling towards the band sawmill while it is running. [See Figure 2]

### LOADING LOGS

 **WARNING!** Risk of entrapment between the log and the band sawmill.

 Always stand to one side of the log table when handling the logs. [See Figure 3, area A]

 Try not to stand between the log table/log pile and the band sawmill. The log pile must always be secured when you are in area B [see Figure 3].

 The logs must be rolled off the log table. Do not drop them onto the band sawmill.

### When loading a log:

1. Place the saw carriage as far back on the rail as possible (its starting position).

2. The log supports must be raised to their top position when loading logs from the operator's side. The log supports must be moved over to the opposite side of the rail (the operator's side) and mounted in their top position when loading logs from the left side of the band sawmill. The log supports are moved back to the left side of the band sawmill when the log is stable on the rail.

3. If the log table comes with a detachable ramp, fit it so that there is no gap between the log table and the band sawmill.

4. Disconnect the locking device for the front logs on the log table.

5. Roll out a log.

6. Secure the logs at the very front of the log pile.


7. Carefully roll the log onto the log supports of the band sawmill. Use a log turner. Centre the log laterally over the crossbars of the log bed.

8. Adjust the log supports so that they support the log but do not come into contact with the saw blade. Lock the log supports in position.

9. Adjust the log clamps so that they are in the middle of the log supports on opposite sides of the log. Adjust the height of the log clamps to lock the log in place. However, ensure that the log clamps cannot come into contact with the bandsaw blade.

# OPERATING INSTRUCTIONS

## OP:1



## OP:2




Figure 2




Figure 3

## OPERATING INSTRUCTIONS

### ADJUSTING THE SAW KERF

The position of the saw head can be adjusted in increments to set the depth of the cut. The B751 PRO band sawmill comes equipped with 1", 1 1/2", 1 3/4" and 2" gauges with saw kerf compensation as standard. The cutting depth is set using the crank on the saw head. Crank down until the mark on the selected gauge is level with the pointer.

### SAWING

**WARNING!** Cutting tools:

**!** Always stand behind the saw carriage and keep both hands on the handle when operating the machine. Never stand in front of the saw carriage or saw blade. Never pull the saw carriage back through a kerf.


**WARNING!** Read through and follow all safety instructions described under *Before each saw kerf* in the *Safety instructions* section.

1. Before using the sawmill, perform all the checks described under *Before each use* in the *Safety instructions* section.

2. Raise the log supports by unhooking them and placing them at the preferred height.

**WARNING!** Risk of entrapment.


**!** Watch your fingers when the log supports are lowered. Check that the log supports are pushed down properly into the fixed positions.



3. Use the log turner accessory when rolling a log onto the log bed. Centre the log on the log bed and roll it towards the log supports. Check the position of the log on the log bed. To ensure the log is cut fully in half, the end must not lie beyond the last crossbar.

4. Rotate the log into a position that gives the best sawing yield.

5. If the log clearly tapers from one end to the other, it is necessary to compensate for this in order to achieve the best possible results. You should always try to saw parallel to the centre line of the log. Place a spacer between the crossbar of the log bed and the narrow end of the log.




*Using a spacer.*



## OPERATING INSTRUCTIONS

**6.** Secure the log using the log clamps. Adjust the height of the log clamps, but do not position them so high that the saw blade may come into contact with them.



*Log clamps. Use of two log clamps is recommended.*

**7.** Set the height of the saw head for the first kerf using the kerf depth crank. Turning the crank clockwise raises the saw head, and turning it anticlockwise lowers it.

**8.** Check that the saw blade runs clear of the log supports and log clamps.

**9.** Set the adjustable saw blade guard to allow for the widest part of the log.

**10.** Open the saw blade flushing valve so that water drips onto the blade guide roller/saw blade.

**11.** Before each saw kerf, perform all checks referred to under *Before each saw kerf* in the *Safety instructions* section.

**12.** Stand behind the push handle of the saw carriage, then start the combustion engine. Open the throttle by squeezing the dead man's switch all the way in. This will increase the speed of the combustion engine to its operating range, and the band wheels/saw blade will start to move.

**13.** Placing both hands on the push handle, carefully push the saw carriage forward until the saw blade starts to cut into the log. The feed rate can be increased once the entire bandsaw blade is engaged in the log. Keep adjusting the feed rate to ensure the kerf is straight and smooth. Reduce the feed rate when cutting through knots in the log, and select a lower feed rate when sawing coarser logs and harder timber varieties. Also reduce the feed rate as you approach the end of the log.


**14.** As soon as you have sawn through the log, release the dead man's switch and stand still until the saw blade has come to a complete stop. Tip: The blade will stop more quickly if you release the throttle just before the blade cuts through the log.

**15.** Remove the sawn section from the log.

**16.** Raise the saw head slightly and return the saw carriage back to its starting position by hand.

**17.** Set the height of the next kerf. Use the crank and read off the gauges.

**18.** Turn the log through 180° so that the freshly sawn surface is lying against the log bed.




*Turn the log through 180° so that the freshly sawn side faces towards the log bed.*

Lower the log supports and log clamps so that they cannot come into contact with the saw blade, then clamp the log in position. Saw until you achieve the preferred block width.

## OPERATING INSTRUCTIONS

Turn the log through 90° so that one of the freshly sawn sides rests against the log supports, then clamp the log in position. Now you can make the third kerf and obtain finished boards. It may be necessary to compensate for the taper of the log in this situation. Lower the saw supports as you go and saw up the block with the bark facing down.



### HANDLING OF SAWN TIMBER

When sawing boards from the block, you can either lift them off the block straight away or leave them where they are and saw a number of planks before handling the timber.

When then lifting the planks off the rail, take care to ensure that the saw head is locked to one of the ends of the rail. Then move the sawn timber to a stacking area. Place straw between the layers of planks to facilitate drying.

*Turn the log through 90° so that one of the freshly sawn sides rests against the log supports, then clamp the log in position.*

**19.** When the log has been turned for the last time in order to saw the last few boards, it is necessary to work out where to start so that everything lines up at the end. It is possible to check this by lowering the saw blade so that it rests against the log. It is then possible to use the absolute gauge to read off how much timber is left under the saw blade. Set the saw head to the preferred height.

**TIP:** The easiest way to go about it is to hold off on turning the block until there is only enough material left for a 2". Counting is then unnecessary.

# MAINTENANCE

## MAINTENANCE

The periodic maintenance on the machine that is expected to be performed by the operator is described in this section. Be sure to follow the specified maintenance intervals, as this is the basis for good function of the sawmill.



**WARNING!** Risk of serious injury:



Turn the ignition switch to OFF and close the fuel valve before servicing or performing maintenance on the machine.



**WARNING!** Cuts:



Coiled bandsaw blades may unexpectedly burst open with considerable force. Handle coiled bandsaw blades with great care.



**WARNING!** Fire risk:



Do not smoke or carry out any work (welding, grinding, etc.) on the band sawmill that could cause sparks that may potentially cause ignition in the vicinity of fuel or combustible materials.



Immediately clear up any fuel spilt on the machine while refuelling it. Change your clothes immediately if you get fuel on them.



Never run the engine if there is a fuel or oil leak. Always turn the engine off before refuelling.

## MAINTENANCE

### HANDLING SAW BLADES

 **WARNING!** Cutting tools: Incorrect handling of bandsaw blades may result in potentially fatal injuries. Saw blades are extremely sharp.

 **WARNING!** Risk of sustaining cuts.

 **When handling saw blades:**

- always wear protective leather gloves (class 1)
- always wear close-fitting protective eyewear or a visor
- wear protective footwear with saw protection, steel toe-caps and non-slip soles
- always wear full-length protective trousers
- keep persons and animals at a safe distance, at least 5 m

### REPLACING BANDSAW BLADES

It is important to replace the saw blades regularly for maximum cutting performance. Fifteen to thirty logs can normally be sawn before replacing the blade, but this is very much dependent on how contaminated the bark is. Using blunt saw blades will result in crooked or incomplete kerfs, reduced saw blade service life and greater risk of saw blade breakage. Always wear protective leather gloves when handling saw blades.

#### To remove the saw blade:

1. Release the blade tension by turning the T-handle counter-clockwise.
2. Open the covers over the band wheels.
3. Remove the saw blade from the band wheels.

#### Fitting a new saw blade:

1. Position the saw blade under the blade guides first and then round the band wheels. Make sure that the saw teeth point towards you
2. Rotate the bandsaw blade by hand in the kerf direction and check that the tracking of the bandsaw blade has not changed. See setting the longitudinal blade position on page 25.
3. Replace the band wheel guards.
4. Close the hatch.

### LUBRICATION POINTS

It is important to lubricate the components of the sawmill as described below in order to ensure your sawmill remains in good condition for many years, and to ensure problem-free ownership. Lubrication must be carried out:

- Immediately after assembly and before starting to use the sawmill.
- Every 50 hours of operation, but at least once a year.

The lubricants to be used on the sawmill are:

- |                             |                    |
|-----------------------------|--------------------|
| • Superflo                  | SKU: 9999-000-5115 |
| • Universal lubricating oil | SKU: 9999-000-5105 |
| • Silicone                  | SKU: 9999-000-5110 |
| • Grease                    | ISO-L-XCCIB2       |

#### Rail pipe sections

Lubricant: Universal lubricating oil

Insert the nozzle of the spray can into all openings and spray the inside of the pipe sections to protect against corrosion.

#### Top sections of the rail on which the saw carriage travels

Lubricant: Universal lubricating oil

#### Blade tensioning T-handle

Lubricant: grease or Superflo

Unscrew the T-bar and apply copious amounts of lubricant to the threaded rod.

#### Saw head lifting chains and chain transmission

Lubricant: Superflo

Lubricate the whole chain.

#### Lifting winch shaft

Lubricant: Superflo

Grease both sides from the outside.

#### The petrol engine's throttle cable and handle

Lubricant: Superflo

Lubricate the joints of the handle and spray oil into the cable from the ends. If the cable is hard to move, remove the cable from its housing, lubricate it along its entire length and spray oil into the cable housing.

#### Saw carriage main post

Lubricant: Silicone

Lubricate the sliding surfaces of the saw head and the plastic guides.

# MAINTENANCE

## CLEANING THE BAND SAWMILL

Clean the band sawmill after every shift. Brush out any wood chips or sawdust inside the band wheel guard and on and around the rail. Wipe painted surfaces and plastic parts with silicone spray (SKU: 9999-000-5110). Lubricate moving parts with Superflo (SKU: 9999-000-5115).

## WATER RESERVOIR

Drain the water from the reservoir and pipes if the temperature falls below zero. Washer fluid may be used as a lubricant at sub-zero temperatures. Never use glycol or flammable liquids as coolant.

## HORIZONTAL SAW BLADE ALIGNMENT

Check before every shift that the saw blade is parallel to the log bed.

## COMBUSTION ENGINE

Check the oil level in the engine before every shift. Follow the maintenance schedule in the instruction manual for the engine.

## SAW HEAD LIFTING CHAINS

Check the saw head lifting chains for damage. Replace the chains if necessary.

## CHECKING SAFETY FEATURES

Before every shift, check that the following safety features are working: Check that the throttle handle returns so that the engine idles when the handle is released. If it does not, lubricate the throttle cable with Superflo (SKU: 9999-000-5115). Check that the switch in the saw guard hinge is working. Check by opening the covers with the engine off and listening for the switch to trip.

## RAIL FLATNESS

Check the balance of the rail before every shift, especially in winter when ground frost may affect the surface.

## BAND WHEEL BELTS

Check the condition of the drive wheel belt and belt of the undriven wheel at regular intervals. Replace any worn or damaged parts. Check the drive belt tension at regular intervals, and adjust if necessary.

## BLADE GUIDES

Check the condition of the blade guide rollers at regular intervals and ensure that the distance between the blade guide roller flange and the bandsaw blade is within 3 to 5 mm. Replace worn or damaged blade guides.

## BAND WHEEL GUARDS

Clean the inside of the band wheel guards and the saw blade to remove any sawdust build-up once an hour when working, or when replacing saw blades.

## BANDSAW BLADE

Replace the bandsaw blade with a new, sharp one after about every two hours of efficient sawing.

## TROUBLESHOOTING SCHEDULE

| PROBLEM/SYMPTOM                                                                                   | PROBABLE CAUSE                                                                                                                                                                                                                                                                                                                                                            | ACTION                                                                                                                                                                                                                                                                                                                                                                 |
|---------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The saw blade quickly loses its edge                                                              | <ul style="list-style-type: none"> <li>• Dirty logs</li> <li>• The saw blade is worn out</li> </ul>                                                                                                                                                                                                                                                                       | <ul style="list-style-type: none"> <li>• Avoid dragging the logs over the ground.</li> <li>• Debark the log at the point where the saw blade is to cut</li> <li>• Saw square blocks off the logs before sawing boards to reduce the number of cuts made through bark.</li> <li>• Replace the saw blade</li> </ul>                                                      |
| Crooked kerf                                                                                      | <ul style="list-style-type: none"> <li>• Blunt saw blade</li> <li>• Feed rate too fast</li> <li>• Feed rate too slow</li> <li>• Sawing into partially frozen log</li> </ul>                                                                                                                                                                                               | <ul style="list-style-type: none"> <li>• Regrind the saw blade</li> <li>• Reduce the feed rate</li> <li>• Increase the feed rate</li> <li>• Leave the log to thaw or become completely frozen before sawing. <b>TIP:</b> Do not approach the log tentatively; allow the blade to make contact with the end of the log directly at an adapted cutting speed.</li> </ul> |
| The saw blade works downwards or upwards while you saw                                            | <ul style="list-style-type: none"> <li>• Inadequate saw blade tensioning</li> <li>• Feed rate too fast</li> <li>• Saw blade damaged</li> <li>• Saw blade not tracking properly over the band wheels</li> </ul>                                                                                                                                                            | <ul style="list-style-type: none"> <li>• Increase the saw blade tension</li> <li>• Reduce the feed rate</li> <li>• Replace the saw blade</li> <li>• Fit the saw blade correctly and adjust the tracking</li> </ul>                                                                                                                                                     |
| Bandsaw blade breakage                                                                            | <ul style="list-style-type: none"> <li>• The saw blade is worn out</li> <li>• Saw blade blunt and/or fitted incorrectly</li> <li>• Saw blade over-tensioned</li> <li>• The blade guide rollers have not been fitted to match the band wheels</li> <li>• Worn shoes on the band wheels resulting in the bandsaw blade coming into direct contact with the metal</li> </ul> | <ul style="list-style-type: none"> <li>• Replace the saw blade</li> <li>• Regrind the saw blade</li> <li>• Reduce the saw blade tension</li> <li>• Adjust the blade guides</li> <li>• Replace shoes on the band wheels</li> </ul>                                                                                                                                      |
| Uneven thickness of sawn wood                                                                     | <ul style="list-style-type: none"> <li>• The saw bed is springy due to insufficient support</li> </ul>                                                                                                                                                                                                                                                                    | <ul style="list-style-type: none"> <li>• Support the rail and log bed as instructed</li> </ul>                                                                                                                                                                                                                                                                         |
| The saw blade does not track and backs out of the band wheels                                     | <ul style="list-style-type: none"> <li>• Incorrect band wheel adjustment</li> <li>• Worn band wheel linings</li> </ul>                                                                                                                                                                                                                                                    | <ul style="list-style-type: none"> <li>• Adjust the band wheels as instructed</li> <li>• Replace the linings</li> </ul>                                                                                                                                                                                                                                                |
| The saw blade does not cut                                                                        | <ul style="list-style-type: none"> <li>• Saw blade installed in the wrong direction</li> </ul>                                                                                                                                                                                                                                                                            | <ul style="list-style-type: none"> <li>• Remove the saw blade, turn it inside out and then refit it</li> <li>• When using the electric motor, check that the motor is running in the right direction, action: Reverse the electric motor.</li> </ul>                                                                                                                   |
| The saw blade is under tension even though the blade tension has been released using the T-handle | <ul style="list-style-type: none"> <li>• The blade tensioning mechanism is seized</li> </ul>                                                                                                                                                                                                                                                                              | <ul style="list-style-type: none"> <li>• Push the T-handle inwards</li> </ul>                                                                                                                                                                                                                                                                                          |
| The saw head is hard to move up and down                                                          | <ul style="list-style-type: none"> <li>• The vertical guides are too narrow</li> <li>• The drum of the saw head's lifting winch needs lubricating</li> </ul>                                                                                                                                                                                                              | <ul style="list-style-type: none"> <li>• Lubricate with silicone, and loosen the guides slightly where appropriate</li> <li>• Lubricate with Superflo</li> </ul>                                                                                                                                                                                                       |
| The saw head rattles when it is lowered                                                           | <ul style="list-style-type: none"> <li>• The rail component is not flat and breaks in the saw carriage</li> </ul>                                                                                                                                                                                                                                                         | <ul style="list-style-type: none"> <li>• Weigh down the rail component as instructed so that it is flat</li> </ul>                                                                                                                                                                                                                                                     |
| The saw blade overheats when sawing                                                               | <ul style="list-style-type: none"> <li>• There is no more water in the water tank</li> <li>• The water valve is closed</li> </ul>                                                                                                                                                                                                                                         | <ul style="list-style-type: none"> <li>• Top up water</li> <li>• Open the water valve</li> </ul>                                                                                                                                                                                                                                                                       |
| The motor/engine will not start                                                                   | <ul style="list-style-type: none"> <li>• The ignition switch is set to "OFF"</li> <li>• The cover switch is enabled</li> </ul>                                                                                                                                                                                                                                            | <ul style="list-style-type: none"> <li>• Turn the ignition switch to "ON"</li> <li>• Check function</li> </ul>                                                                                                                                                                                                                                                         |





## Declaration of Conformity

In accordance with Directive 2006/42/EC, Annex 2A

Logosol AB  
Arkivvägen 6  
871 53 Härnösand

hereby declares that **Logosol B751 PRO**

has been manufactured in conformity with:  
the Machinery Directive 2006/42/EC, the EMC Directive  
2014/30/EU

and has been manufactured in conformity with the following  
harmonised standards:

EN ISO 12100:2010, EN 60204-1:2018,  
EN 50370-1:2005, EN 50370-2:2003.

Notified body, 0404, RISE SMP Svensk Maskinprovning AB, Box  
7035, SE-750 07 Uppsala, Sweden, has performed EC type  
examination according to Directive 2006/42/EC, Article 12(3b).  
The EC type examination certificate is numbered: 0404/17/2408

The band sawmill supplied is identical to the band sawmill that  
underwent EC type examination.

**Härnösand, 30 January 2026**

A handwritten signature in black ink, appearing to read 'R. Berglund', is written over a horizontal line.

**Robert Berglund, CEO**

# LOGOSOL

Arkivvägen 6, SE-871 53 Härnösand  
+46 (0)611-182 85 | [info@logosol.com](mailto:info@logosol.com) | [www.logosol.com](http://www.logosol.com)